

RF TUNE
F5K
TUNING
PTO
MIXER
DRIVER
RCVR RF AMP
IF AMP
AUDIO
XMIT AGC
RCVR K
XMIT K
SIDEBAND
BAND
LOWER
UPPER
MICROPHONE
CARRIER BALANCE
SIDETONE OSC.
DET.-1ST AF AMP
XMIT GAIN (GANGED W/R74)
XMIT GAIN (GANGED W/R98)
RELATIVE OUTPUT
PLATE AMPS
ANTENNA
EXTERNAL RCVR ANT
EXTERNAL RCVR MUTE
TO ALL RCVR K
TO ALL XMIT K
TO PINS 5 & 8 OF J3
VOX
ANTI-VOX
RELAY
S METER
SENSITIVITY
ZERO
PHONES
MODE
SSB X-CW
CAL
X-AM
RCVR GAIN
RCVR AGC (SOURCE)
R.F. GAIN
AUDIO PRE-AMP
RCVR-AUDIO OUTPUT
XMIT-ANTI VOX
TO PIN 12 OF J3
TO N.O. CONTACTS OF K1
PART OF R91
XMIT AGC (FROM V13 B PLATE)
POWER SUPPLY RECP
FIL. FUSE
TO J5 (PHONES)
12.6 V AC
6.3 V AC
LIGHTS
EXTERNAL VFO
BLANKER
KEY
LOAD
TUNE
PLATE
SCREEN
DRIVER
MIXER
RCVR
XMIT
AGC
RF
AF
IF
VOX
RELAY
ANTI-VOX
SIDETONE
CARRIER
BALANCE
MICROPHONE
BAND
LOWER
UPP